

# APV Hybrid - Welded Heat Exchanger

WITH MULTI-FLEXIBLE CONFIGURATION FOR ROBUST AND EFFICIENT HEAT TRANSFER





## About APV

SPX provides advanced APV heat transfer solutions for cooling, heating, condensing and evaporation of process fluids - designed to solve heat transfer process challenges in a vast array of industries. They are designed to meet demanding process conditions and to optimize the utilisation of energy. APV heat transfer solutions have proven reliable and highly efficient helping customers worldwide to run their processes safely and economically.

Since APV invented the plate heat exchanger in 1923 we have been pioneering applicable technology in pressing, shaping, welding, sealing and testing steel. Dedicated and specialized SPX staff around the world is committed to design and provide efficient and durable heat transfer solutions to help customers optimize energy utilization and minimize downtime for improved profitability.

# Choosing the right Heat Exchanger can be a complex matter

### HOW CAN ONE SINGLE HEAT EXCHANGER TECHNOLOGY COVER ALL YOUR KEY PRIORITIES?

- In a complex decision process, neglecting key priorities may lead to low performance or even plant failure things you would re-do if you could.
- With more than a century of heat exchanger experience, SPX knows the needs and priorities of most industries.
- Let SPX guide you through complex choices to the right solution for your specific application and needs.

#### IF THESE ARE SOME OF YOUR PRIORITIES...

	WHAT COULD HAPPEN IF YOU COMPROMISE HERE?	WHAT CAN YOU EXPECT FROM SPX AND HYBRID?	
Very high working temperature, (including temperature shocks)	Equipment failure/ replacement	Longer production uptime	
Very high working pressure (including pressure shocks)	Equipment failure/ replacement	Longer production uptime	
Small footprint	High conversion/ engineering costs	Cost savings, accessibility	
High heat recovery, extreme small log mean temperature difference	Higher running costs	Cost savings, lower $\rm{CO}_2$ footprint	
Cleanability, manual and CIP	Reduced efficiency	Operation at desired specifi- cation after cleaning	
Resistance to corrosion	Equipment failure/ replacement	Long service life	

#### ... HYBRID IS FOR YOU!

Based on a multi-flexible configuration platform, Hybrid is designed to operate under harsh conditions where other heat exchanger technologies can fail, have a shorter operating lifetime, or reduce operational efficiency.

What's more, easy access makes high-pressure cleaning of Hybrid plates simple, effective and fast!

# The heart of the matter

The central plate core is contained by 4 movable pressure panels, and the 2 flows are separated by the plate wall and 4 corner bars.

### GENERAL USE

- ✔ 350°C (662°F)
- ✓ Up to 40 barg design pressure (580 psig)
- Corrosive media
- ✔ Gas/steam/air with low pressure drop
- ✔ Pass-through of particles/solid

# Typical product applications

#### Oil and Gas

Gas sweetening Gas Dehydration Crude oil stabilizer Crude oil heater

**Chemical** Solution cooler and heater Process condenser Cryogenic chiller

**Power** Steam condenser District heating units









Industrial Reboiler



### 6 BASIC MODELS



MODEL	24	12	8	6	4	2
Height mm (Inch)	1450 (57)	1050 (41)	1050 (41)	1050 (41)	1050 (41)	1050 (41)
Length mm (Inch)	3300 - 3575	3300 - 3575	2440 - 2710	2010 - 2280	1580 - 1850	1150 - 1425
	(130 - 141)	(130 - 141)	(96 - 107)	(79 - 90)	(62 - 73)	(45 - 56)
Width mm (Inch)	715 - 1075	715 - 1075	610 - 785	610 - 785	610 - 785	390 - 785
	(28 - 42)	(28 - 42)	(24 - 31)	(24 - 31)	(24 - 31)	(15 - 31)

**Note:** Dimensions are approximate and may vary as per specific model configuration. The APV Hybrid can be mounted horisontal or vertical.

# ... to meet all your needs

- We will always find the perfect solution
- Perfect adaptability for almost any application
- Full utilisation of pressure drop to maximise thermal efficiency
- Close temperature approach of both media, down to 1°C possible (1.8°F)
- Low pressure drop possible even at high mass flows even for gas/steam
- Perfect for condensation and evaporation (including vacuum condensation)
- Large connection sizes possible
- Non-symmetric flows handled, even with perfect pressure drop utilisation



# Unseen flexibility based on a range of standard variants...

EXAMPLE 1



Low number of passes on tube side in combination with single pass on corrugated side system for low NTU value applications and/or low pressure drop requirements

EXAMPLE 2



Single pass on tube side in combination with multiple passes on corrugated side for multiphase applications (e.g. condensation)

EXAMPLE 3



High number of passes on tube side in combination with corrugated multiple passes for close temperature approach applications (heat recovery)

# 3 plate variants – depending on your needs

## HYBRID FEATURES 3 VERY DIFFERENT PLATE TYPES!



# Do fouling or scaling impact your production planning?

- Spare capacity, filter systems or CIP cleaning systems are expensive to install.
- 2 of the 3 plate options can be cleaned effectively using manual high pressure cleaning.



### HUGE FLEXIBILITY BASED ON STANDARD VARIANTS

MODEL	24	12	8	6	4	2			
model			, in the second	Ŭ					
Heat transfer in m² (ft²)	170-464 (1830-4995)	85-232 (915-2498)	45-103 (484-1109)	34-77 (366-829)	22-51 (237-549)	5-26 (54-280)			
Max. nozzle size Tube side	DN500 20"	DN450 18"	DN450 18"	DN300 12"	DN300 12"	DN450 18"			
Max. nozzle size Corrugated side	DN500 20"	DN350 14"	DN350 14"	DN350 14"	DN350 14"	DN350 14"			
Material plates	Standard: 1.4404 (316L), 1.4547 (254 SMO) On request: 1.4571 (316Ti) / 1.4301 (304) / 1.4539 (904L)								
Design temperature	According to PED 97/23 EC: -40°C to 350°C (-40°F to 662°F) According to ASME VIII: -28°C to 350°C (-18.4°F to 662°F)								
Design pressure	Up to 40 barg (580 psig) Including full vacuum								
Design code	PED 97/23 EC / EN 13445 (AD2000) ASME. VIII, Div. 1								
Flange ratings	Welded neck flanges EN 1092-1 / ANSI B16.5								
Nozzle loads	API 662 Table I API 662 Table II								

#### **Customisation Options:**

- Plates in other alloys
- Fully welded vessel construction (not openable)
- Venting options
- Sub cooling
- Up to 1.800 m<sup>2</sup> (19,375 ft<sup>2</sup>) heat transfer area in one unit
- Higher design pressures available depending on application and design requirements
- Panel gasket material: Graphite as standard, PTFE on request





# Hybrid - Welded Heat Exchanger

WITH MULTI-FLEXIBLE CONFIGURATION FOR ROBUST AND EFFICIENT HEAT TRANSFER

## **Global locations**

#### SPX FLOW TECHNOLOGY

Platinvej 8 6000 Kolding Denmark T: +45 70 278 444 F: +45 70 278 445 E-mail: apv.emea.heat@spx.com

#### SPX FLOW TECHNOLOGY

666 Fengjin Road Xidu Industrial Park Fengxian P.R. China Tel: 86 21 67158181 Fax: 86 21 67158282

#### SPX FLOW TECHNOLOGY

1200 West Ash Street P.O. Box 1718 Goldsboro North Carolina 27533-1718 USA T: +1 (919) 735-4570 F: +1 (919) 731-5498 E-mail: answers.us@apv.com

#### ABOUT SPX

Based in Charlotte, North Carolina, SPX Corporation (NYSE: SPW) is a global multi-industry manufacturing leader. For more information, please visit www.spx.com.

SPX FLOW TECHNOLOGY

Platinvej 8 6000 Kolding, Denmark P: (+45) 70 278 444 F: (+45) 70 278 445 E: apv.emea.heat@spx.com

SPX reserves the right to incorporate our latest design and material changes without notice or obligation.

Design features, materials of construction and dimensional data, as described in this bulletin, are provided for your information only and should not be relied upon unless confirmed in writing. Please contact your local sales representative for product availability in your region. For more information visit www.spx.com. The green ">" is a trademark of SPX Corporation, Inc..

APV-1208-GB Version: 05/2014 Issued: 05/2014